



## Moulded Premium Heavy Duty Floor Mats Part Number 140210086MAT

## SAFETY INFORMATION - READ BEFORE INSTALLING

Please Note, The Floor Mats may need to relax back into shape having been folded in the box.

Remove all previously installed floor mats and/or debris from vehicle floor to ensure proper fit.

Use great care to install your Moulded Premium Heavy Duty Floor Mats in the correct location per enclosed instructions.

Be sure to always use any existing or provided retention system so the Floor mats are properly secured.

Inspect vehicle control pedals for full freedom of movement after installation and before each use. DO NOT DRIVE VEHICLE IF ANY INTERFERENCE EXISTS AT ANY TIME.

Check the fit of the Floor Mats frequently, particularly after vehicle is washed, serviced or Floor Mats are reinstalled.

Place this warning/instruction label in the owner's manual of your vehicle so that all drivers have access to this information.